
Impact™ Backplane Module Installation Press-In Tool



# Application Tooling Specification Sheet



## Order No. 62203-0375

# **FEATURES**

- Polarized tool prevents product damage
- Tool provides uniform distribution of press force across entire pin array
- May be used as a stand-alone tool or mounted in an optional holder with other Molex press-in tools

#### SCOPE

<u>Products</u>: Impact<sup>™</sup> Orthogonal Backplane Signal Module Assembly, 76285 Series, (6-Pair by 10 Column Assemblies). See Product List below for specific part numbers.


### **Product List**

The following is a partial list of the product order numbers and their specifications this tool is designed to run. Updates to this list are available on <u>www.molex.com</u>.

76285 Series Numbers								
Guide Style	Columns	Assembly Order Number						
Open Wall	10	76285-0104	76285-0105	76285-0107	76285-0108	76285-1104	76285-1105	
		76285-1107	76285-1108					
Dual End	10	76285-0124	76285-0125	76285-0127	76285-0128	76285-1124	76285-1125	
		76285-1127	76285-1128					
Left End	10	76285-2104	76285-2105	76285-2107	76285-2108	76285-3104	76285-3105	
		76285-3107	76285-3108	76285-6104	76285-6105	76285-6107	76285-6108	
		76285-7104	76285-7105	76285-7107	76285-7108			
Right End	10	76285-4104	76285-4105	76285-4107	76285-4108	76285-5104	76285-5105	
		76285-5107	76285-5108	76285-8104	76285-8105	76285-8107	76285-8108	
		76285-9104	76285-9105	76285-9107	76285-9108			

# **Tool Setup**

Depending on the number of connectors to be installed and/or the press used, this tool can be used alone or with a group of press-in tools, mounted in a 62201-95XX rail (ordered separately). See Figure 1.



Doc No: ATS-622030375 Revision: A Release Date: 05-01-12 Revision Date: 05-01-12

## UNCONTROLLED COPY

Page 1 of 3

# **Tool Installation**

The 62201-95XX rail is available in a variety of lengths to accommodate multiple press-in tools.

Rail Part Number	Rail Overall Length
62201-9501	24mm (0.94 in)
62201-9502	72mm (2.83 in)
62201-9503	156mm (6.14 in)
62201-9504	216mm (8.50 in)
62201-9509	254mm (10.0 in)
62201-9511	305mm (12.0 in)

Reference: This Press-In Tool is 20.95mm (0.82 in.) long.

# Printed Circuit Board (PCB) Support

The Impact<sup>™</sup> connectors require up to 3.6kg (8 lb) of force per pin to press into the PCB. To prevent excessive PCB flexure and/or damage to the PCB, a support plate is strongly recommended directly beneath the connector hole pattern.

Due to the custom nature of every application, Molex does not offer any PCB support plate. The customer must furnish their own support plate.

When creating the PCB support plate, remember to allow clearance for the connector pins as they pass through the PCB thickness.


#### **Press Equipment Recommendations**

Many types of presses can be used to install Impact<sup>™</sup> connectors, but to assure consistent connector installation Molex recommends the following press criteria:

- 1. The capability to detect force variations as low as 4.5kg (10 lb) during the press-in cycle; excessive force measurements should stop the press-in cycle.
- 2. The rate of pressing can be regulated as low as 0.13mm (0.005 in) per second.
- 3. Press stroke control to within 0.25mm (0.010 in).
- 4. Total press stroke must be at least 19mm (0.75 in).
- 5. For statistical purposes, automatic collection of force and distance data.


## **Tool Operation**

- Insert by hand the backplane signal module assembly (s) carefully into the PCB hole pattern. Make sure the connector(s) are oriented properly by confirming the location of the #1 circuit notch with respect to the PCB layout.
- 2. Insert the Press-In Tool making sure that the notch in this tool is inserted into the slot on top of the connector housing of the backplane signal module assembly. See Figure 2.



3. Using the application tool and an appropriate press, seat the header assembly until there is less than 0.10mm (.004 in) clearance between the bottom of the plastic housing and the surface of the PCB. See Figure 3.

There should be no broken stand-offs along the perimeter of the part (an indication of over-pressing).



**CAUTION**: To prevent injury, never operate any press without the guards in place. Refer to the press manufacturer's instruction manual.

**CAUTION**: Molex application tooling specifications are valid only when used with Molex connectors and tooling.

#### **Contact Information**

For more information on Molex application tooling please contact Molex at 1-800-786-6539.

http://www.molex.com

Doc No: ATS-622030375 Revision: A Release Date: 05-01-12 Revision Date: 05-01-12 UNCONTROLLED COPY